

Essem Design

Stativset dubbel Nostalgi klädställ grund

Tillbehör till Nostalgi hatt- & skohylla för att få ett fristående dubbelsidigt klädställ

Innehåll:

1 st. Vänster- & 1 st. högerstativ, 2 st. stag, 1 st. beslagspåse (4 st. ställfötter, 6 st. 30x40 ändplugg, 4 st. Täckpropp, 4 st. M10 skruv, 1 st. insexyckel, 16 st. M6 skruv, 16 st. skruvhattbricka och 16 st. skruvhatt)

Monteringsanvisning: (se även bild nedan)

1. Två personer för att montera rekommenderas. Verktyg som behövs är stjärnskruvmejsel och liten spårskruvmejsel. Testskruva alla gängor försiktigt innan montage.
2. Montera ställfötter och 30x40 ändplugg på vänster- och högerstativen. Har ni köpt till golvfästen så se bifogad anvisning.
3. Om det ska vara inklusive påbyggnadsdel, se bifogad anvisning för detta. Annars hoppa över denna.
4. Montera stag mellan vänster- och högerstativ uppe och nere med M10 skruv och insexyckel. Dra inte åt skruvarna förrän allt är monterat. De stora hålen på stativen ska vara utåt.
5. Om det ska vara inklusive spaljéset, se bifogad anvisning för detta. Annars hoppa över denna.
6. Öppna upp Nostalgi förpackningen och montera konsolerna på stativen med skruvhattbricka och M6 skruv. Glöm inte skruvhatten för dold skruv.
7. Trä på ankarkrokarna på rundstavarna så som önskas. Ni behöver inte sätta fast dem än. Sätt ditt rundstavarna mellan konsolerna.
8. Dra åt stagen ordentligt. Dra varannan sida för att det inte ska bli skevt. Tryck ditt täckproppen efter.
9. Skruva ditt stoppskruvarna på konsolerna och ankarkroken.



Essem Design

Set of stands double – Nostalgi coat stand

Accessories for the Nostalgi hat and shoe rack to make a free-standing double-sided coat stand.

Contents:

1 X Left & 1 X Right upright, 2 X horizontal braces, bag of fittings (4 X feet, 6 X 30x40 end plugs, 4 X cover caps, 4 X M10 bolts, 1 X hex key, 16 X M6 bolts, 16 X bolt head cover washers and 16 bolt head covers)

Assembly instructions: (see also image below)

1. We recommend assembly is a two-person job. Tools required: a crosshead screwdriver and a small slotted screwdriver. Carefully test screw in all bolts before assembly.
2. Attach the feet and 30x40 end plugs to the left and right uprights. If you have bought floor fixings, please see attached instructions.
3. If additional accessories are included, please see attached instructions for these. Otherwise jump to next step.
4. Affix the upper and lower braces between the left and right uprights with the M10 bolts and hex key. Do not fully tighten the bolts until everything has been assembled. The large holes in the uprights should face outwards.
5. If a trellis set is included, please see attached instructions for these. Otherwise jump to next step.
6. Open the Nostalgi packaging and mount the brackets onto the frame with the M6 bolts and head cover washers. Do not forget the head covers for the concealed bolts.
7. Insert the anchor hooks on the round bars into the desired positions. You do not need to tighten them yet. Insert the round bars between the brackets.
8. Fully tighten the braces. Tighten both sides to ensure it is not crooked. Press the cover caps into place.
9. Tighten the adjustment screws on the brackets and anchor bolts.

